


Replacement Parts & Accessories




695XL Gas Concrete Saw


TABLE OF CONTENTS 695XL Gas Saw

| ITEM DESCRIPTION | KEY | PAGE |
|--|-----|------|
| | | |
| 695XL Gas Saw Service Items | n/a | 2 |
| | | |
| Starter Assembly | A | 3 |
| Flywheel & Ignition Assembly | В | 4 |
| Clutch Assembly & WallWalker® | С | 5 |
| Side Cover & Tensioner Assembly | D | 6 |
| Cylinder & Exhaust Assemblies | E | 7 |
| Crankcase Assembly | F | 8 |
| Crankshaft Assembly | G | 9 |
| Carburetor & Intake Assemblies | I | 11 |
| Cylinder & Air Filter Cover Assemblies | J | 12 |
| Fuel Tank Assembly | K | 13 |
| Water Delivery System | L | 14 |


SERVICE ITEMS 695XL Gas Concrete Saw




| Key# | Part No. | Description |
|-----------|----------|--|
| 1 | 71541 | Pressure Gauge Bulb |
| 2 | 71543 | Cylinder Assembly Clamps & Piston Stop |
| 3 | 71565 | Electronic Tachometer |
| 4 | 546191 | Workshop Key Torx T27 |
| 6 | 546193 | Air Gap Gauge |
| 7 | 546194 | Flywheel Puller |
| 8 | 547277 | Piston Stop |
| 9 | 546196 | Wrist Pin Punch |
| 10 | 546197 | Cylinder Seal, Exhaust |
| 11 | 546198 | Cylinder Seal, Inlet Port |
| 12 | 546289 | Puller, Sealing Ring |
| 13 | 546292 | Universal Puller |
| 14 | 546293 | Grip Plate |
| 16 | 546295 | Bearing Press |
| 17 | 546307 | Screwdriver, Idle |
| not shown | 546659 | Clutch Tool |
| not shown | 544120 | Flat Blade Scrench |
| not shown | 544119 | Torque Scrench |
| not shown | 70249 | 14T Bar Nose Sprocket Repair Kit (for 695GC) |
| not shown | 571227 | OIL, 2-STROKE 2.6 OZ(6-PACK) |




| Key# | Part No. | Description |
|------|----------|-------------------------|
| A1 | 544013 | STARTER COVER ASSEMBLY |
| A2 | 544127 | STARTER PULLEY KIT, 695 |
| A3 | 544023 | STARTER CORD |
| A4 | 544024 | STARTER HANDLE |
| A5 | 544012 | SCREW |
| A6 | 544026 | STARTER COVER SHIELD |




| Key # | Part No. | Description |
|-------|----------|---|
| B1 | 544030 | STOP SWITCH SCREW |
| B2 | 544031 | STOP SWITCH |
| В3 | 544032 | STOP SWITCH CABLE |
| B4 | 544033 | SPARK PLUG CAP |
| B5 | 544034 | SPARK PLUG |
| В6 | 544035 | PROTECTIVE SLEEVE |
| B7 | 544036 | IGNITION MODULE |
| B8 | 544038 | IGNITION MODULE SCREW |
| В9 | 544053 | FLYWHEEL |
| B10 | 544125 | STARTER PAWL KIT (INCL. TWO OF EACH ITEM) |
| B11 | 544058 | STARTER WASHER |
| B12 | 544059 | STARTER NUT |




| Key# | Part No. | Description |
|------|----------|----------------------------|
| C1 | 543905 | RETAINING RING |
| C2 | 551384 | SPLIT RETAINER, 695 (PAIR) |
| C3 | 543907 | SPACER |
| C4 | 525496 | 695F4 FORCE4® SPROCKET |
| C4 | 70949 | 695GC RIM SPROCKET |
| C5 | 543909 | CLUTCH CUP |
| C6 | 543910 | NEEDLE BEARING |
| C7 | 543911 | BAR BRACKET SCREW |
| C8 | 543912 | CRANK CASE BOLT |
| C9 | 544130 | WALLWALKER® |
| C10 | 543920 | WALLWALKER® SCREW |
| C11 | 543915 | WATER PIPE |
| C12 | 546548 | WATER PIPE SCREW |
| C13 | 543916 | BAR BRACKET |
| C14 | 547856 | CLUTCH KIT |
| C15 | 543928 | CLUTCH SPRING |
| C16 | 544137 | SHIELD |




| Key# | Part No. | Description |
|------|----------|--------------------------------|
| D1 | 543899 | SIDE COVER (INCLUDES #D2 & D3) |
| D2 | 543900 | SIDE COVER NUT |
| D3 | 543901 | SIDE COVER NUT CIRCLIP |
| D4 | 543902 | TENSIONER COVER PLATE |
| D5 | 543903 | SCREW, SIDE COVER CAP |
| D6 | 543904 | TENSIONER |



| Key# | Part No. | Description |
|------|----------|------------------------------|
| E1 | 543942 | CYLINDER/MUFFLER SCREW |
| E2 | 576169 | PISTON/CYLINDER KIT |
| E3 | 543844 | HEAT DEFLECTOR |
| E4 | 543938 | MUFFLER GASKET |
| E5 | 543845 | MUFFLER |
| E6 | 543846 | LOWER MUFFLER MOUNTING SCREW |
| E7 | 543847 | MUFFLER MOUNTING WASHER |
| E8 | 576166 | DECOMPRESSION VALVE |
| E9 | 576165 | CYLINDER BASE GASKET |
| E10 | 543949 | NEEDLE BEARING |
| E11 | 543936 | GASKET KIT |
| E12 | 543931 | SEALING RING |
| E13 | 543933 | CRANKCASE GASKET |




| Key# | Part No. | Description |
|------|----------|----------------------|
| F1 | 576170 | CRANKCASE ASSEMBLY |
| F2 | 543930 | CRANKCASE SCREW |
| F3 | 543931 | SEALING RING |
| F4 | 543932 | GUIDE BUSHING |
| F5 | 543933 | CRANKCASE GASKET |
| F6 | 543934 | MAIN BEARING |
| F7 | 543935 | RUBBER BUSHING |
| F8 | 543936 | GASKET KIT |
| F9 | 543937 | CYLINDER BASE GASKET |
| F10 | 543938 | MUFFLER GASKET |
| F11 | 544129 | BAR STUD KIT |
| F12 | 543941 | BAR BRACKET FASTENER |




| Key# | Part No. | Description |
|------|----------|---------------------|
| G1 | 543952 | CRANKSHAFT ASSEMBLY |
| G2 | 543934 | MAIN BEARING |
| G3 | 543953 | CRANKSHAFT SHIELD |
| G4 | 543949 | NEEDLE BEARING |


THIS PAGE INTENTIONALLY LEFT BLANK




| Key# | Part No. | Description |
|------|----------|--|
| I1 | 544069 | INLET BOOT CLAMP |
| 12 | 544070 | INLET BOOT |
| 13 | 544071 | FLANGE |
| 14 | 544072 | FLANGE CLUTCH SIDE SCREW |
| 15 | 544073 | FLANGE BRACKET |
| 16 | 544065 | SCREW |
| 17 | 544074 | SEPARATOR PLATE |
| 18 | 544075 | CARBURETOR (WALBRO RWJ-7) |
| 19 | 544111 | THROTTLE CABLE LEVER |
| I10 | 576168 | ADJUSTMENT GUIDE |
| l11 | 544112 | MANIFOLD BRACKET |
| l12 | 544113 | AIR INTAKE MANIFOLD |
| l13 | 544114 | AIR FILTER BRACKET |
| 114 | 544115 | CARBURETOR MOUNTING SCREW |
| l15 | 543975 | THROTTLE CABLE ASSEMBLY |
| l16 | 544117 | CHOKE LEVER |
| l17 | 576161 | CARBURETOR REPAIR KIT (Only for 695XL, will not fit 695GC/F4/PG) |



| Key# | Part No. | Description |
|------|----------|---|
| J1 | 544060 | FILTER COVER REAR SCREW |
| J2 | 544061 | FILTER COVER FRONT SCREW |
| J3 | 576167 | PLUG (may be required on older 695GC/F4 models) |
| J4 | 544062 | FILTER COVER |
| J5 | 544063 | AIR INTAKE INSERT |
| J6 | 544064 | AIR FILTER |
| J7 | 544065 | CYLINDER COVER SCREW |
| J8 | 544067 | CYLINDER COVER SEALS |
| J9 | 544066 | CYLINDER COVER ASSEMBLY |



| Key# | Part No. | Description |
|------|----------|------------------------------|
| K1 | 543812 | FUEL TANK ASSEMBLY |
| K2 | 543813 | PARALLEL PIN |
| K3 | 543814 | CABLE LEVER |
| K4 | 543815 | THROTTLE LOCK OUT LEVER |
| K5 | 543816 | REAR HANDLE COVER |
| K6 | 543818 | CLIP |
| K7 | 543993 | FUEL LINE |
| K8 | 543994 | CHECK VALVE TUBE |
| K9 | 543969 | CHECK VALVE |
| K10 | 543970 | HOSE CLAMP |
| K11 | 543971 | FUEL FILTER |
| K12 | 544990 | TANK VENT ELBOW |
| K13 | 544122 | TANK VENT |
| K14 | 543972 | REAR HANDLE GROUND SUPPORT |
| K15 | 543973 | PURGE BULB |
| K16 | 543974 | REAR HANDLE SCREW |
| K17 | 543975 | THROTTLE CABLE ASSEMBLY |
| K18 | 543976 | THROTTLE TRIGGER |
| K19 | 543977 | TRIGGER SPRING |
| K20 | 543995 | PURGE BULB TUB |
| K21 | 543979 | GAS TANK CAP ASSEMBLY |
| K22 | 543981 | SHOCK ABSORBER SCREW |
| K23 | 543982 | SHOCK ABSORBER CLUTCH SIDE |
| K24 | 543983 | SHOCK ABSORBER FRONT |
| K25 | 543984 | SHOCK ABSORBER FLYWHEEL SIDE |



| Key # | Part No. | Description |
|-------|----------|-------------------------------------|
| L1 | 543996 | WATER HOSE VALVE ASSEMBLY |
| L2 | 547969 | HOSE HANGER |
| L3 | 543999 | WATER HOSE WITH PROTECTIVE COVERING |
| L4 | 544000 | CLAMP, WATER HOSE |
| L5 | 544001 | CLAMP, WATER HOSE VALVE SIDE |
| L6 | 544002 | FRONT HANDLE |
| L7 | 544003 | SHOCK ABSORBER, FRONT HANDLE |
| L8 | 543981 | SCREW, SHOCK ABSORBERS |
| L9 | 544008 | CLIP, FRONT HANDLE |
| L10 | 544009 | SCREW, FRONT HANDLE |
| L11 | 576679 | MUD FLAP |
| L12 | 544011 | BACKING PLATE, MUD FLAP |
| L13 | 544012 | SCREW, MUD FLAP |

695XL Replacement Parts & Accessories Price List

ICS Diamond Tools and Eqippment, Oregon Tool 4909 SE International Way Portland, OR 97222

> P: 800.321.1240 E: icsdiamondtools.com